

How to Install and Configure DD Free Dish to Receive Transmission on SWAYAMPBABHA Channels?

Two-step process for configuring and installing DD Free Dish and Set-top box, generally available with all TV dealers for less than Rs. 2,000/-, is as follows:

Step 1:

Install DD Fresh Dish as per the directions given at: [http://ddindia.gov.in/Technical/Pages/DD-Free-Dish-\(DTH\).aspx](http://ddindia.gov.in/Technical/Pages/DD-Free-Dish-(DTH).aspx)

Step 2:

Set following parameters in the Set-top box for SWAYAM PRABHA Channels:

a) Parameters for SWAYAM PRABHA channel No.1 to 16:

Downlink Frequency: - 11590 MHz
Polarization: - Vertical
LNB Frequency: - 9750
Symbol Rate: - 29500 Ksps FEC: $\frac{3}{4}$

b) Parameters for SWAYAM PRABHA channel No. 17 to 32:

Downlink Frequency: - 11670 MHz
Polarization: - Vertical
LNB Frequency: - 9750
Symbol Rate: - 29500 Ksps FEC: $\frac{3}{4}$